

## Gold Mount Battery Reader: Data Output

Slide the Reader onto the rear battery contacts and data will automatically display. The menu category is displayed on the left, and the reading for the battery is displayed on the right. A single press of the button on the right moves selection onto the next category; the left button moves it back to the previous category.

### Percentage State of Charge:



### Available Capacity in Ampere-Hours:



### Cell Temperature:



### Number of Charge/Discharge Cycles:



### Voltage (Potential Difference):



### Full Capacity in Ampere-Hours:



### Date of Birth (Month/Year):



### Software Version:



### Serial Number:

