

V-Mount Battery Reader: Data Output

Slide the Battery Reader onto the battery contacts and data will automatically display. The menu item title is followed by the reading for the battery. The display alternates between the two until a single press of the up-button moves it onto the next item. The sequence is as follows:

Percentage State of Charge:



Available Capacity in Ampere-Hours:



Cell Temperature:



Number of Charge/Discharge Cycles:



Voltage (Potential Difference):



Full Capacity in Ampere-Hours:



Date of Birth (Month/Year):



Software Version:



Internal Firmware:

